

# REJUVENATION

## Rock Creek House Number

**CALIFORNIA PROPOSITION 65 WARNING:** This product contains brass hardware components which contain lead, a heavy metal known by the State of California to cause cancer, birth defects, or other reproductive harm.

### PARTS INCLUDED:

House Number	1 pc	Mounting Pin	2 pcs
Template	1 pc		

**TOOLS REQUIRED:** Pencil, Drill with an appropriate size bit.

### INSTALLING INSTRUCTIONS

Note: Mounting pins are provided for mounting to wood siding. Please consult your local hardware store for assistance when mounting on walls made of alternate material.

1. Determine the desired mounting location for your house number(s). Using the supplied template, mark the locations of mounting pins.
2. Use a 11/64inch diameter drill bit and an appropriate drill to make holes at these marks. Drill each hole for 1-1/2" in depth.
3. Threading mounting pins into the back of house number, and insert the spacers. Apply a small amount of clear adhesive caulk in each hole and press the house number posts firmly into the previously drilled holes. Note: Gently tapping with a hammer over a piece of wood may be necessary to fully seat the number.

### CARE INSTRUCTIONS

Wipe with a soft, dry cloth. To protect the finish, do not use household cleaners or abrasives.

