

# REJUVENATION®

## Clawfoot Tub Installation Instructions

---

**Tools Needed:** 1 1/16" wrench

**Materials Included:** Tapered rubber shims, 4 claw feet, 4 bolts, 4 flat washers, 4 lock washers, 4 nuts

1. Remove plastic wrapping from tub.
2. Cut and remove strapping from around tub.
3. Remove foam rim protector.
4. Check tub paint and porcelain for any imperfections or damage.
5. Remove and inspect the feet for any scratches or rust.
6. Fold and lay down a blanket on the floor to place the tub on when you remove it from the crate.

*NOTE: It can be helpful to place some form of blocking under the rim during step 8 so that you will be able to get your hands under the tub to flip it back over when finished.*

7. Remove the tub from the crate and place it rim down on the blanket. The tub will now be resting upside down so that the tub bottom should be pointing at the ceiling.
8. Set out feet so that the letter on the bottom of the foot corresponds to the letter that is located beside the lugs on the bottom of the tub.
9. Take bolt and insert into the lugs so that the threads are pointing towards the ceiling.
10. Take foot and place over bolt and gently lower so that the foot rests on both the tub and the tongue and lug. (The tongue is the flat area that extends back from the foot and consists of the mounting hole for the bolt.)

*CAUTION: The foot can scratch the side of the tub if it is not placed gently over the bolt.*

11. Place flat washer over bolt on top of the foot tongue.
12. Place lock washer over flat washer.
13. Place nut over lock washer and tighten it to within 1/8" of the lock washer. (This will allow you enough space to adjust the foot as needed.)
14. IF THE FOOT LIES FLUSH on both the side of the tub and between the foot tongue and lug, CONTINUE to step 20.
15. IF THE FOOT DOES NOT LIE FLUSH, loosen the nut so that it rests approximately 1/21' away from the washer.
16. Take one of the provided shims and place it between the foot's tongue and tub lugs.

*NOTICE: The shims are tapered so be sure to insert the shims so that the largest end of the shim rest in the largest space between tongue and lug.*

17. IF FOOT LIES FLUSH on both surfaces, continue to step 20.
18. IF FOOT DOES NOT LIE FLUSH, repeat process in step 17 until you've reached the desired outcome.
19. Once foot lies flush on both the side of the tub and between the tongue and lug, tighten the nut.

*CAUTION: DO NOT OVER-TIGHTEN NUTS. Over tightening will cause the bolts to strip and become unusable.*

20. After nut is tightened, gently shake the foot to make sure there is no movement in the foot.
21. Flip the tub right-side up and make sure that it rests stationary on the floor. (When reflipping the tub, be sure to not put all of the tubs weight on only two tub feet.)
22. If the tub does not remain stationary, establish which corner is causing the unevenness, flip tub back over, and shim the appropriate corner.
23. Repeat steps 22 & 23 until desired outcome is reached.