

# REJUVENATION

## West Slope Pivot Mirror Bracket

### PARTS INCLUDED

Support Brackets	2 pcs	Drywall Anchors	4 pcs
Mounting Screws	4 pcs	Allen wrench	1 pc

Pivot Mirror (sold separately) 1 pc

### MOUNTING INSTRUCTIONS FOR TYPICAL DRYWALL APPLICATIONS

**Note:** Consult your local hardware store for proper mounting to other wall materials.

Tools required: Slotted screwdriver, pencil, tape measure, and level.

1. Loosen set screws from bottom of both support brackets.
2. Place one of the brackets in desired location.
3. Mark the location of drywall anchor installation. Remove the brackets from the wall. Using a Phillips head screwdriver, pierce the tip of the anchor into the wall and turn clockwise until anchor is flush with the wall.
4. Once both anchors are in place, install the bracket.
5. Using a tape measure and level, determine the location for the second mounting plate (center of first bracket to center of second bracket). Repeat steps.
6. Slip the second bracket onto the mirror. With a helper, carefully lift the mirror into place. Install the second mirror bracket screws.
7. Tilt the mirror to desired angle and tighten set screws to hold in place.

### CARE INSTRUCTIONS

To maintain and protect the luster of all products, clean with a soft, damp cloth only. To protect the finish, do not use household cleaners or abrasives.

