

REJUVENATION®

West Slope Hook

CALIFORNIA PROPOSITION 65 WARNING: This product contains brass hardware components which contain lead, a heavy metal known by the State of California to cause cancer, birth defects, or other reproductive harm.

PARTS INCLUDED:

Single Hook	1 pc
Mounting Screws	2 pcs
Drywall Anchors	2 pcs

Maximum total weight capacity for this product is 35 pounds (15.9 kg).

MOUNTING INSTRUCTIONS FOR TYPICAL DRYWALL APPLICATIONS

Note: Consult your local hardware store for proper mounting to other wall materials.

Tools required: Phillips and slotted screwdriver, Pencil.

1. Position single hook in desired location on wall.
2. Mark the locations of drywall anchor installation. Remove the single hook from the wall. Using a screwdriver, pierce the tip of the anchor into the wall. *Do not pound the anchors into the wall, they are designed to bore into the wall like a screw.* Turn clockwise until the anchor is flush with the wall.
3. Once both anchors are in place, place the single hook over the anchors and insert mounting screws. Turn mounting screws clockwise just until you feel resistance.

CLEANING INSTRUCTIONS

To maintain and protect the luster of all products, clean with a soft, damp cloth only.

