



NOTE: Recommended in showers where a waterproof membrane/ shower pan liner is generally used.

NOTE: Decorative DRAIN should be installed only after all flooring is completed. Use WHITE PLASTIC MUDGUARD (supplied) to properly set HEAD onto BODY.

1. Connect drain BODY to pre-installed drain pipe using:
 - a. ABS plastic pipe solvent cement for ABS BODY (SD-ABS-2/3)
 - b. PVC plastic pipe solvent cement for PVC BODY (SD-PVC-2/3)
 - c. No-hub connector for Cast IRON BODY (SD-CST-2/3)
2. To obtain proper grid DRAIN height, rotate adjustable HEAD to raise or lower. One complete rotation of HEAD is equal to 1/8" in vertical adjustment. Use WHITE PLASTIC MUDGUARD in lieu of decorative DRAIN to properly set height and level off with tile.
3. Score line between the tile and drain with utility knife once grout is firming. Refer to grout manufacturer's installation instructions for setting times.
4. After completion of finished flooring, remove WHITE PLASTIC MUDGUARD and apply the grille.

Note: Always remove grille before using drain cleaners.