



REJUVENATION

LIGHTING & HOUSE PARTS




PATH LIGHT
INSTALLATION INSTRUCTIONS



1. To prevent electrical shock, disconnect transformer from electrical supply before installation or service. (This step applies to both path and directional lighting)
2. Run wire pigtail from luminaire through the mounting hole in top of ground stake. (This step applies to both path and directional lighting)
3. Thread luminaire into threaded hole in ground stake. (This step applies to both path and directional lighting)
4. Place stake in desired position and insert into ground until flange of stake is flush to grade. (This step applies to both path and directional lighting)
5. Strip the (2) leads from the luminaire pigtail wire. (This step applies to both path and directional lighting)

6



7



NOTE: Avoid aiming fixture directly upward. Whenever possible, set at angle to prevent rain or irrigation water from settling on lens.

6. Using the two (2) silicone filled safety connectors (provided), connect the leads from the luminaire to the main supply cable leads. (Connections must be water tight.) **NOTE: Luminaires are supplied with 36" of 18-2 cable pigtail for secure connection to the main supply cable. The wire is to be protected by routing in close proximity to the luminaire. The wiring should be buried a maximum depth of 6 inches (15.2 cm) in order to connect to the main supply cable. (This step applies to both path and directional lighting)**

7. Aim luminaire to desired angle. Lock into place by tightening Phillips screw in adjustable knuckle. To avoid abrasion and damage to cable do not remove adjustment screw in knuckle to. Only loosen until swivel become adjustable. *(This step applies to directional lighting)*

LAMP INSTALLATION/ REPLACING LAMP

1. Make sure power is turned off or unplug fixture and allow the lamp to cool.
2. Do not touch lens! Lens maybe extremely hot!
3. Make sure any material that can catch fire is removed or relocated away from the lamp.

***TO PREVENT ELECTRICAL SHOCK, ALWAYS REMEMBER TO DISCONNECT TRANSFORMER FROM ELECTRICAL SUPPLY BEFORE SERVICING. ALWAYS WORK WITHOUT LIVE FEED ON.**

THANK YOU FOR YOUR PURCHASE

2550 NW Nicolai Street, Portland Oregon 97210 • Customer Service: 888 401-1900 • www.rejuvenation.com