
Williams-Sonoma Inc.

Pottery Barn – Pottery Barn Teen – Pottery Barn Kids – Williams Sonoma Home – West Elm – Rejuvenation – Mark and Graham

14-SEP-2020 1/2



BLAIR KNOB/PULL/BIN PULL

Williams-Sonoma Inc.

Pottery Barn - Pottery Barn Teen - Pottery Barn Kids - Williams Sonoma Home - West Elm - Rejuvenation - Mark and Graham

14-SEP-2020 2/2

CALIFORNIA PROPOSITION 65 WARNING: This product can expose you to chemicals including Lead which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65warnings.ca.gov.

PARTS INCLUDED


Knob:1 pc,1pc 8-32 1" Truss head screw,1 pc 8-32 1-1/2" Truss head screw Pull/ Bin Pull:1pc, 2 pcs 8-32 1" Truss head screw,2 pc 8-32 1-1/2" Truss head screws

MOUNTING INSTRUCTIONS

This knob/Pull includes hardware that is designed to mount securely to drawer-fronts or cabinet doors that have a thickness range between 1/2" and 1-1/2" inches. If you drawer- front or door is thicker or thinner than this range, please obtain the appropriate size screw from your local hardware store.

Knob: Carefully determine a desired knob location and use a 3/16 inch diameter drill bit and an appropriate drill to make the hole through the drawer/door front. Insert the appropriate length screw. Attach the knob onto the protruding threads of the screw and rotate clockwise until snug. Use a screwdriver to tighten the screw while gently holding the knob.

Pull/Bin Pull: Carefully determine a desired pull location. Use 3/16 inch diameter drill bit and appropriate drill to make the holes through the drawer-front / door with the proper center to center distance matching your pulls. Insert the appropriate length screws from the back of the drawer / door front, Attach the drawer pull onto the protruding threads of the screws. Use a screwdriver to tighten the screws while gently holding the drawer pull



CLEANING INSTRUCTIONS

- 1. Dust often using a clean, soft, dry and lint-free cloth.
- 2. Blot spills and wipe with a clean, damp cloth immediately.
- 3. We do not recommend the use of chemical cleansers, abrasives or furniture polish on our lacquered finish.
- 4. Hardware may loosen over time. Periodically check to make sure all connections are tight. Re-tighten if necessary

© 2020 Williams-Sonoma, Inc.