





Unpack and check all the parts, and read the instructions.

PART NO.	DESCRIPTION	QTY
BKT-A	SUPPLY LINE LOOP RING	2
BKT-B	SHORT SCREW	3
BKT-C	SUPPLY LINE LOOP	2
BKT-D	LONG SCREW	3
BKT-E	ROD	3
BKT-F	COUPLING	1
BKT-G	DRAIN LOOP	1
BKT-H	DRAIN LOOP RING	1